

# Wireless Microphone Quick Start Guide

The purpose of this quick start guide is to get you working with the microphone quickly. If you have further questions, please reference the online training video, which can be found at the following link:

[theloftstage.org/wireless-training](http://theloftstage.org/wireless-training)



## Microphone Transmitter Types

There are two different microphone types available with your system. If you need hands free operation of the mic, then the bodypack transmitter would be ideal, but if you are going to be passing the mic around a lot or singing, then the handheld transmitter is the better choice.

### HANDHELD TRANSMITTER



### BODYPACK TRANSMITTER



## Powering On

To power on the transmitter, toggle the on/off switch. The switch on the handheld transmitter can be found just below the LCD screen on the side of the mic and the switch on the bodypack transmitter can be found on the top near the antenna.

## Batteries

Each microphone takes 2 AA batteries. The batteries in the handheld transmitter are replaced by unscrewing the bottom half of the mic housing. The bodypack transmitter batteries are replaced by pressing on the two tabs on the side at the same time and lifting the flap.

## Mic Usage

Every system will have at least one receiver that has multiple wireless transmitters. For instance, you may find that there is a *Wireless 1* handheld transmitter and a *Wireless 1* bodypack transmitter. This allows the system to be more flexible, but it is important to know that only 1 of these transmitters can be used at the same time.